



TENTS | AUDIO VISUAL | DANCE FLOOR | STAGING | LINENS | DISHWARE

# Country Drink Dispenser 1.5 Gal

The **Country Drink Dispenser 1.5 Gal** is designed to deliver in a small space sufficient reason for an inviting pull effect, teas, coffee, natural fruit juices as well as other beverages with no pulp. Quick to install and straightforward to use. Thanks to the reduced size is easily placed in any area, from bars to tables.

1. Rinse container with clear water before each use.
2. Place container where it will be used.
3. Turn the faucet to the off position prior to filling.
4. Fill container with desired drink. Be careful that you don't overfill the container, especially if you are wanting to add ice.
5. Add ice. By adding ice last, it will help prevent the container from cracking.
6. Keep your hand on the tap and gently shake the container for the cleanser to reach all elements of the beverage dispenser.
7. Drain cleaner through the actual tap and clean the interior and exterior of the bowl with the damp kitchen.
8. Rinse the dispenser and faucet with very hot water and let fresh air dry.

## Cleaning Instructions

1. Run any remaining beverage out of the dispenser through the faucet.
2. Fill the container with 1 liter of water, 1 teaspoon dish soap in addition to 2 teaspoons white vinegar to disinfect.
3. Keep your hand on the tap and gently shake the container for the cleanser to reach all elements of the beverage dispenser.
4. Drain cleaner through the actual tap and clean the interior and exterior of the bowl with the damp kitchen.
5. Rinse the dispenser and faucet with very hot water and let fresh air dry.

Any damages made to the machine due to misuse, you the customer will be responsible to pay for the cost to replace the damaged machine.